

## D9 ADJUSTABLE STOP

### NOTE:

- 1) REMOVE HEX NUT AND LOCKWASHER
- 2) ROTATE ADJUSTABLE STOP TO DESIRED POSITION
- 3) REPLACE LOCKWASHER AND HEX NUT

